



2/2-way Diaphragm Valve with stainless steel design, welded or clamp connection, DN 8-50

- Hermetical separation of fluids from the operating mechanism by diaphragm
- Zero dead volume
- Various surface finishes
- Certified according to
- Clean design for optimal use in hygienic environment

Type 2103 forged On/Off can be combined with...





Type 8691

Pneum. control unit with feedback

Control Head

The externally piloted diaphragm valve consists of a pneumatically operated piston actuator, a diaphragm and a 2-way valve housing made of forged stainless steel. The high-quality actuator with a stainless steel cover is designed for usage in hygienic or aggressive environments.

The flow optimised and zero dead volume valve body makes high flow rates possible and a variety of applications to be realised.

The design enables the easy integration of automation modules whether they are electrical/optical position feedback, pneumatic control units, an integrated fieldbus interface or even an explosion proof feedback.

The fully integrated system has a compact and smooth design, integrated pneumatic lines, IP65/67/NEMA4X protection class and superior chemical resistance.







Type 8695

Control Head

Type 8645Automation system FreeLINE

Type 8222
Conductivity
transmitter

Technical data	
Orifice	8 to 50
Body material	Forged stainless steel 316L / 1.4435/BN2
	Fe < 0.5% / C ≤ 0.03%
Actuator material	
Actuator	PPS
Cover	Stainless steel 1.4561 (316Ti)
Diaphragm materials	EPDM, PTFE/EPDM (advanced PTFE/EPDM,
	FKM on request)
Media	Neutral gases and liquids, high purity, sterile,
	aggressive or abrasive fluids
Viscosity	up to viscous
Surface finishes	(average surface finish)
internal mechanical polished	
(external forged surface)	Ra ≤ 0.6 μm
On request:	
internal electro polished (external	
forged surface electro polished)	Ra ≤ 0.4 μm
internal mirror finished	Ra ≤ 0.25 µm
Medium temperatures	
EPDM, PTFE/EPDM,	
advanced PTFE/EPDM (on request) ¹⁾	-10 to +130 °C (briefly up to +150°C for steam sterilisation)
FKM on request	-10 to +130°C
Ambient temperature	+5 to +60 °C
Control medium	Neutral gases, air
Max. pilot pressure	max. 10 bar, 7 bar with actuator size 130 mm
Port connections Welded acc.	EN ISO 1127/ISO 4200, DIN 11850 Series 2,
	ASME BPE, BS4825, SMS 3008 (on request)
Clamp acc.	DIN 32676, ASME BPE, ISO 2852 (on request)
Sterile threaded ports	on request
Pilot air ports	Push-in connector for external ø 6 mm or 1/4" tube,
	thread G1/8 (on request)
Installation	as required, preferably with actuator in upright position

Advanced PTFE/EPDM is recommended for sterilization cycle

Content





Technical data valves

Kv-value

Orifice	•	Kv value water	Actuator size Ø	Permitte pressure	•	Max. operating pres for seal material	sure [bar]
[mm]	[inch]	(m³/h)	[mm]	min.	max.	EPDM, FKM [bar]	PTFE/EPDM and advanced PTFE/EPDM [bar]
8	1/4″	1.0	50	5	10	10	10
10	3/8"	1.0	50	5	10	10	10
15	1/2″	5.5	70	5	10	10	10
20	3/4"	10.0	70	5	10	10	10
25	1″	14.0	70	5	10	6.5	6
			90	5.5	10	10	8
40	1 1/2"	30.0	130	5.0	7	10	10
50	2"	51.5	130	5.0	7	8	7


Flow rate: Kv value water (m³/h)

Measured at +20 °C, 1 bar pressure at valve inlet and free outlet.


Pressure values (bar)

Measured as overpressure to the atmospheric pressure.

Installation for self-draining operation



 $\alpha=15$ up to 35° (Marking must face upwards, 12 o'clock position) plus 3° to 5° inclination to the pipe axis. Drain marks permanently marked on both sides of the valve body show the correct mounting position to optimise drain ability.






Approvals

Suitability for foodstuffs / sterile applications



- The composition of the EPDM, PTFE/EPDM and advanced PTFE/EPDM diaphragms corresponds to the Code of Federal Regulations, published by the FDA (Food and Drug Administration, USA).
 - The EPDM diaphragms correspond to the KTW Recommendation (Plastics in the Drinking Water Sector). A Manufacturer's Declaration will be supplied on request.

Materials






Ordering chart Type 2103 forged diaphragm valve

Welded connection, surface finish mechanical polished, Ra \leq 0.6 μ m, further on request

	Orifice			<u> </u>		ar]	ar]	<u>a</u>
Control	[mm]	[inch]	External-Ø [mm]	Kv value water (m³/h)	Actuator size ø [mm]	Pilot pressure [bar]	Max. operating pressure [bar]	Item no. mechanichal polished, Ra ≤ 0.6 μm
	Acc. to E	N ISO 1127	/ISO 4200					
A 2/2-way valve, normally closed (NC)	Diaphrag	m material	EPDM					
ciosed (NC)	8	1/4″	13.5	1.0	50	5-10	10	218 005
A	15	1/2″	21.3	5.5	70	5-10	10	218 006
⊳ <u>[</u>	20	3/4″	26.9	10.0	70	5-10	10	218 007
P	25	1″	33.7	14.0	70	5-10	6.5	218 008
					90	5.5-10	10	218 009
	40	1 1/2″	48.3	30.0	130	5-7	10	218 010
	50	2″	60.3	51.5	130	5-7	8	218 011
	Diaphrag	m material	PTFE/EPDM					
	8	1/4″	13.5	1.0	50	5-10	10	218 012
	15	1/2″	21.3	5.5	70	5-10	10	218 013
	20	3/4"	26.9	10.0	70	5-10	10	218 014
	25	1″	33.7	14.0	70	5-10	6	218 015
					90	5.5-10	8	218 016
	40	1 1/2"	48.3	30.0	130	5-7	10	218 017
	50	2″	60.3	51.5	130	5-7	7	218 018
	Acc. to D	IN 11850 S	erie 2					
	Diaphrag	m material	EPDM					
	10	3/8"	13	1.0	50	5-10	10	218 019
	15	1/2″	19	5.5	70	5-10	10	218 020
	20	3/4″	23	10.0	70	5-10	10	218 021
	25	1″	29	14.0	70	5-10	6.5	218 022
					90	5.5-10	10	218 023
	40	1 1/2″	41.0	30.0	130	5-7	10	218 024
	50	2″	53.0	51.5	130	5-7	8	218 025
	Diaphrag	m material	PTFE/EPDM					
	10	3/8″	13	1.0	50	5-10	10	218 026
	15	1/2″	19	5.5	70	5-10	10	218 027
	20	3/4"	23	10.0	70	5-10	10	218 028
	25	1″	29	14.0	70	5-10	6	218 029
					90	5.5-10	8	218 030
	40	1 1/2"	41.0	30.0	130	5-7	10	218 031
	50	2″	53.0	51.5	130	5-7	7	218 032



Seal: advanced PTFE/EPDM, FKM

Port connection Welded acc. SMS3008

Control function B (normally open) and I (double-acting)

Additional Further surface finishes



Ordering chart Type 2103 forged diaphragm valve, continued

Welded connection, surface finish mechanical polished, Ra \leq 0.6 μ m, further on request

	2 141							
- u	Orifice		al-Ø	ue [m³/h	för [mm]	<u> 5</u>	ting	o. anical ed, ۱
Control	[m m]	[inch]	External-Ø [mm]	Kv-value water [m³/h]	Actuator size ø [mm]	Pilot pressure [bar]	Max. operating pressure [bar]	ltem no. mechanical polished, Ra ≤ 0.6 μm
	Acc. to A	SME BPE						
A 2/2-way valve, normally	Diaphrag	m material I	EPDM					
closed (NC)	8	1/4″	6.35	1.0	50	5-10	10	218 033
Ą	10	3/8"	9.53	1.0	50	5-10	10	218 034
	15	1/2″	12.7	5.5	70	5-10	10	218 035
P	20	3/4"	19.05	10.0	70	5-10	10	218 036
	25	1″	25.4	14.0	70	5-10	6.5	218 037
					90	5.5-10	10	218 038
	40	1 1/2″	38.1	30.0	130	5-7	10	218 039
	50	2″	50.8	51.5	130	5-7	8	218 040
	Diaphrag	m material I	PTFE/EPDM					
	8	1/4″	6.35	1.0	50	5-10	10	218 041
	10	3/8″	9.53	1.0	50	5-10	10	218 042
	15	1/2″	12.7	5.5	70	5-10	10	218 043
	20	3/4"	19.05	10.0	70	5-10	10	218 044
	25	1″	25.4	14.0	70	5-10	6	218 045
					90	5.5-10	8	218 046
	40	1 1/2"	38.1	30.0	130	5-7	10	218 047
	50	2″	50.8	51.5	130	5-7	7	218 048
	Acc. to B	S 4825						
	Diaphrag	m material I	EPDM					
	8	1/4″	6.35	1.0	50	5-10	10	218 049
	10	3/8″	9.53	1.0	50	5-10	10	218 050
	15	1/2″	12.7	5.5	70	5-10	10	218 051
	20	3/4"	19.05	10.0	70	5-10	10	218 052
	Diaphrag	m material I	PTFE/EPDM					
	8	1/4″	6.35	1.0	50	5-10	10	218 053
	10	3/8″	9.53	1.0	50	5-10	10	218 054
	15	1/2″	12.7	5.5	70	5-10	10	218 055
	20	3/4"	19.05	10.0	70	5-10	10	218 056



Material

Seal: advanced PTFE/EPDM, FKM

Port connection Welded acc. to SMS3008

Control function
B (normally open) and I (double-acting)

Additional

Further surface finishes



Ordering chart Type 2103 forged diaphragm valve, continued

Clamp connection, surface finish mechanical polished, Ra \leq 0.6 μ m, further on request

_	Orifice		Ø	•	_	•	<u>ت</u> ش	ra _ ra
Control	[mm]	[inch]	External-Ø [mm]	Kv value water (m³/h)	Actuator size ø [mm]	Pilot pressure [bar]	Max. operating pressure [bar]	ltem no. mechanical polished, Ra ≤ 0.6 μm
		IN 32676						
2/2-way valve, normally	Diaphrag	m material E	EPDM					
closed (NC)	15	1/2"	34.0	5.5	70	5-10	10	218 057
Α	20	3/4"	34.0	10.0	70	5-10	10	218 058
T T T	25	1″	50.5	14.0	70	5-10	6.5	218 059
					90	5.5-10	10	218 060
r	40	1 1/2"	50.5	30.0	130	5-7	10	218 061
	50	2″	64.0	51.5	130	5-7	8	218 062
		m material F					J	
	15	1/2″	34.0	5.5	70	5-10	10	218 063
	20	3/4"	34.0	10.0	70	5-10	10	218 064
	25	1″	50.5	14.0	70	5-10	6	218 065
	0		55.0		90	5.5-10	8	218 066
	40	1 1/2"	50.5	30.0	130	5-7	10	218 067
	50	2"	64.0	51.5	130	5-7	7	218 068
		SME BPE -			130	5-7	1	216 006
		m material E		31011				
	Biaphrag 8	1/4"	25.0	1.0	50	5-10	10	218 069
	10	3/8"	25.0	1.0	50	5-10	10	218 009
	15	1/2"	25.0	5.5	70	5-10	10	218 071
	20	3/4"	25.0	10.0	70	5-10	10	218 072
	25	1″	50.5	14.0	70	5-10	6.5	218 073
					90	5.5-10	10	218 074
	40	1 1/2″	50.5	30.0	130	5-7	10	218 075
	50	2″	64.0	51.5	130	5-7	8	218 076
		m material F						
	8	1/4″	25.0	1.0	50	5-10	10	218 077
	10	3/8″	25.0	1.0	50	5-10	10	218 078
	15	1/2″	25.0	5.5	70	5-10	10	218 079
	20	3/4"	25.0	10.0	70	5-10	10	218 080
	25	1″	50.5	14.0	70	5-10	6	218 081
					90	5.5-10	8	218 082
	40	1 1/2"	50.5	30.0	130	5-7	10	218 083
	50	2"	64.0	51.5	130	5-7	7	218 084
	Acc. to A	SME BPE -	long dimens	sion				
	Diaphrag	m material E	EPDM					
	8	1/4"	25.0	1.0	50	5-10	10	218 085
	15	1/2″	25.0	5.5	70	5-10	10	218 086
	20	3/4"	25.0	10.0	70	5-10	10	218 087
	25	1"	50.5	14.0	70	5-10	6.5	218 088
	20	'	00.0	1+.0	90	5.5-10	10	218 089
	40	1 1/2"	50.5	20.0	130	5-7		218 099
	50	2"	64.0	30.0	130	5-7	10 8	218 090
		m material F		51.5	130	J-1	0	210 091
	Diaphrag 8	m materiai i 1/4"	25.0	1.0	50	5-10	10	218 092
	15	1/2"	25.0	5.5	70	5-10	10	218 092
	20	3/4"	25.0	10.0	70	5-10	10	218 094
	25	1″	50.5	14.0	70	5-10	6	218 095
					90	5.5-10	8	218 096
	40	1 1/2″	50.5	30.0	130	5-7	10	218 097
	50	2"	64.0	51.5	130	5-7	7	218 098



Material
Seal: advanced PTFE/EPDM, FKM

Control function
B (normally open) and I (double-acting)


Port connection Clamp acc. to ISO 2852



burkert

Dimensions Type 2103 forged diaphragm valve [mm]

Welded connection



EN ISO 1127/ISO 4200 and DIN 11850 S2

All boo	lies										EN ISO 1127/ ISO 4200		DIN 11850 S2	
Orifice	ifice Actuator size Ø													
[mm]	[inch]	[mm]	ØA	В	F	С	R	E	н	LS	Ø DS	ws	Ø DS	ws
8	1/4″	50	64.5	17.15	19.8	6.1	17.15	19.8	129	90	13.5	1.6	-	_
10	3/8″	50	64.5	17.15	19.8	6.1	17.15	19.8	144	110	17.2	1.6	13.0	1.5
15	1/2″	70	91	30.5	23.3	8.5	30.5	23.3	161	110	21.3	1.6	19.0	1.5
20	3/4″	70	91	30.5	23.3	8.5	30.5	23.3	171	119	26.9	1.6	23.0	1.5
25	1″	70	91	30.5	23.3	8.5	30.5	23.3	174	129	33.7	2.0	29.0	1.5
		90	120	30.5	23.3	8.5	30.5	23.3	207	129	33.7	2.0	29.0	1.5
40	1 1/2"	130	159	30.5	23.3	8.5	30.5	23.5	288	161	48.3	2.0	41.0	1.5
50	2"	130	159	30.5	23.3	8.5	30.5	23.5	311	192	60.3	2.0	53.0	1.5

ASME BPE and BS 4825

All boo	dies										ASME	BPE	BS 482	25
Orifice [mm]	[inch]	Actuator size Ø [mm]	ØA	В	F	С	R	E	н	LS	Ø DS	ws	Ø DS	ws
8	1/4″	50	64.5	17.15	19.8	6.1	17.15	19.8	129	78	6.35	0.89	6.35	1.2
10	3/8"	50	64.5	17.15	19.8	6.1	17.15	19.8	144	108	9.53	0.89	9.53	1.2
15	1/2″	70	91	30.5	23.3	8.5	30.5	23.3	161	108	12.70	1.65	12.70	1.2
20	3/4"	70	91	30.5	23.3	8.5	30.5	23.3	171	117	19.05	1.65	19.05	1.2
25	1″	70	91	30.5	23.3	8.5	30.5	23.3	174	127	25.40	1.65	25.40	1.65
		90	120	30.5	23.3	8.5	30.5	23.3	207	127	25.40	1.65	25.40	1.65
40	1 1/2"	130	159	30.5	23.3	8.5	30.5	23.3	288	159	38.10	1.65	38.10	1.65
50	2"	130	159	30.5	23.3	8.5	30.5	23.3	311	190	50.80	1.65	50.80	1.65


On request: SMS 3008

Orifice		Actuator size Ø										
[mm]	[inch]	[mm]	ØA	В	F	С	R	E	Н	LS	Ø DS	ws
25	1″	70	91	30.5	23.3	8.5	30.5	23.3	174	127	25	1.2
		90	120	30.5	23.3	8.5	30.5	23.3	207	127	25	1.2



Dimensions Type 2103 forged diaphragm valve [mm], continued

Clamp connection



DIN 32676

Orifice		Actuator size Ø											
[mm]	[inch]	[mm]	ØA	В	F	С	R	E	н	LC	Ø D1C	Ø D2C	Ø D3C
15	1/2″	70	91	30.5	23.3	8.5	30.5	23.3	161	110	34	27.5	16
20	3/4"	70	91	30.5	23.3	8.5	30.5	23.3	171	119	34	27.5	20
25	1″	70	91	30.5	23.3	8.5	30.5	23.3	174	129	50.5	43.5	26
		90	120	30.5	23.3	8.5	30.5	23.3	207	129	50.5	43.5	26
40	1 1/2"	130	159	30.5	23.3	8.5	30.5	23.5	288	161	50.5	43.5	38
50	2"	130	159	30.5	23.3	8.5	30.5	23.5	311	192	64	56.5	50

ASME BPE

Orifice		Actuator size Ø								LC				
[mm]	[inch]	[mm]	ØA	В	F	С	R	E	н	long dimension	short dimension	Ø D1C	Ø D2C	Ø D3C
8	1/4″	50	64.5	17.15	19.8	6.1	17.15	19.8	129	78	64.5	25	21.8	3.95
10	3/8"	50	64.5	17.15	19.8	6.1	17.15	19.8	144	89	89	25	21.8	9.4
15	1/2″	70	91	30.5	23.3	8.5	30.5	23.3	161	108	89	25	21.8	9.4
20	3/4"	70	91	30.5	23.3	8.5	30.5	23.3	171	117	102	25	21.8	15.75
25	1″	70	91	30.5	23.3	8.5	30.5	23.3	174	127	114	50.5	43.5	22.2
		90	120	30.5	23.3	8.5	30.5	23.3	207	127	114	50.5	43.5	22.2
40	1 1/2"	130	159	30.5	23.3	8.5	30.5	23.5	288	159	140	50.5	43.5	34.9
50	2″	130	159	30.5	23.3	8.5	30.5	23.5	311	190	159	64	56.5	47.6

On request: ISO 2852

Orifice		Actuator size Ø					
[mm]	[inch]	[mm]	Н	LC	Ø D1C	Ø D2C	Ø D3C
25	1″	70	174	129	50.5	43.5	22.6
		90	207	129	50.5	43.5	22.6



Ordering information for valve system On/Off ELEMENT Type 8801-DF

A valve system On/Off ELEMENT Type 8801-DF consists of a diaphragm valve Type 2103 and a pneumatic control unit Type 8690 or control head Type 8691 (for valve actuator sizes ø 70/ø90/ø130 mm) or control head Type 8695 (for valve actuator size ø 50 mm) (see separate datasheets). For the configuration of further valve systems please use the "Request for quotation" on p.14 go to page

You order two components and receive a complete assembled and certified valve.



Click on the orange box "More info." below... you will come to our website for the resp. product where you can download the datasheet.

Pneumatic control unit Type 8690





The new generation of integrated controllers for combination with actuators from the process valve series Type 21xx is specially designed for the requirements of hygienic process environments.

The pneumatic control unit Type 8690 combines electrical position feedback and pneumatic control for single or double-acting actuators.

The pneumatic control unit Type 8690 combines electrical position feedback and pneumatic control for single or double-acting actuators, and is also optionally available as an intrinsically safe model to ATEX.

Main customer benefits:

- Compact design of the valve system with integrated controller meets the demands for plant washdown environments through the selection of materials, external seals and integrated control air supply to the actuator
- Integrated pilot valve with manual actuation
- · Air intake filter enhances the process valve system availability
- Simple and reliable actuator adaptations allowing additional actuators of the process valve series, Type 20xx or actuators from other manufacturers to be used

Control head Type 8691





The new generation of integrated control heads for combination with actuators from the process valve series Type 21xx is specially designed for the requirements of hygienic process environments. The intelligent control head, Type 8691, detects the valve position by means of a contact-free analog position sensor circumventing excessive wear of mechanical parts. Single or double-acting actuators are controlled via the integral pilot valve. Communication interfaces AS-Interface and DeviceNet are available as options.

Main customer benefits:

- Compact, hygienic design of the valve system with integrated controller meets the demands of plant washdown environments through the selection of materials, external seals and integrated control air supply to the actuator
- Automatic setting of the control head at the push of a button
- Even under dirty or dark environments, a clearly visible status display due to powerful LEDs
- Monitoring and diagnosis: Process valve systems with field bus interface used in modern plant processes
- Integrated pilot valve with manual actuation
- Air intake filter enhances the process valve system availability
- Simple and reliable actuator adaptations allowing additional actuators of the process valve series, Type 20xx or actuators from other manufacturers to be used



More



Ordering information for valve system On/Off ELEMENT Type 8801-DF, continued

A valve system On/Off ELEMENT Type 8801-DF consists of a diaphragm valve Type 2103 and a pneumatic control unit Type 8690 or control head Type 8691 (for valve actuator sizes ø70/ø90/ø130 mm) or control head Type 8695 (for valve actuator size ø 50 mm) (see separate datasheets). For the configuration of further valve systems please use the "Request for quotation" on p.14 go to page You order two components and receive a complete assembled and certified valve.




More

Click on the orange box "More info." below... you will come to our website for the resp. product where you can download the datasheet.

Control head Type 8695







Main customer benefits:

- Compact, hygienic design of the valve system with integrated controller meets the demands of plant washdown environments through the selection of materials, external seals and integrated control air supply to the actuator
- Automatic setting of the control head at the push of a button
- Visual status display on the control headMonitoring and diagnosis: Process valve systems with fieldbus interface used in modern plant processes
- Integrated pilot valve
- · Simple and reliable actuator adaption


p. 10/16



Dimensions for valve system On/Off ELEMENT Type 8801-DF [mm]

Dimensions valve system On/Off ELEMENT Type 8801-DF-K with pneumatic control unit Type 8690 [mm]

Welded connection




EN ISO 1127/ISO 4200 and DIN 11850 S2 (SMS 3008 on request)

Orifice		Actuator size			EN ISO 1 ISO 4200		DIN 118 Serie 2	50	SMS 3008 (on request)		
[mm]	[inch]	[mm]	HG	LS	Ø DS	ws	Ø DS	ws	Ø DS	ws	
15	1/2"	70	224	110	21.3	1.6	19	1.5	-	-	
20	3/4"	70	234	119	26.9	1.6	23	1.5	-	-	
25	1"	70	237	129	33.7	2.0	29	1.5	25	1.2	
		90	270	129	33.7	2.0	29	1.5	25	1.2	
40	1 1/2"	130	351	161	48.3	2.0	41	1.5	38	1.2	
50	2	130	374	192	60.3	2.0	53	1.5	51	1.2	

ASME BPE and BS 4825

Orifice		Actuator size Ø			ASME E	BPE	BS 482	5
[mm]	[inch]	[mm]	HG	LS	Ø DS	ws	Ø DS	ws
15	1/2"	70	224	108	12.70	1.65	12.70	1.2
20	3/4"	70	234	117	19.05	1.65	19.05	1.2
25	1"	70	237	127	25.40	1.65	25.40	1.65
		90	270	127	25.40	1.65	25.40	1.65
40	1 1/2"	130	351	159	38.10	1.65	38.10	1.65
50	2	130	374	190	50.80	1.65	50.80	1.65

Clamp connection



DIN 32676 and ASME BPE

Orific	е	Actua- tor size Ø		DIN	32676			ASME B	PE			
[mm]	[inch]	[mm]	HG	LC	Ø D1C	Ø D2C	Ø D3C	LC long dimen- sion	short dimen- sion	Ø D1C	Ø D2C	Ø D3C
15	1/2"	70	224	110	34	27.5	16	108	89	25	-	9.4
20	3/4"	70	234	119	34	27.5	20	117	102	25	-	15.75
25	1"	70	237	129	50.5	43.5	26	127	114	50.5	43.5	22.2
		90	270	129	50.5	43.5	26	127	114	50.5	43.5	22.2
40	1 1/2"	130	351	161	50.5	43.5	38	159	140	50.5	43.5	34.9
50	2	130	374	192	64.0	56.5	50	190	159	64	56.5	47.6

On request: ISO 2852


Orifice		Actuator size Ø					
[mm]	[inch]	[mm]	HG	LC	Ø D1C	Ø D2C	Ø D3C
25	1″	70	237	129	50.5	43.5	22.6
		90	270	129	50.5	43.5	22.6



Dimensions for valve system On/Off ELEMENT Type 8801-DF [mm], continued

Dimensions valve system On/Off ELEMENT Type 8801-DF-H with control head Type 8691 [mm]

Welded connection




EN ISO 1127/ISO 4200 and DIN 11850 S2 (SMS 3008 on request)

Orifice	•	Actuator size Ø			EN ISO ISO 420		DIN 118 Serie 2		SMS (on re	3008 quest)
[mm]	[inch]	[mm]	HG	LS	Ø DS	WS	Ø DS	ws	Ø DS	ws
15	1/2"	70	257	110	21.3	1.6	19	1.5	-	-
20	3/4"	70	267	119	26.9	1.6	23	1.5	-	-
25	1"	70	270	129	33.7	2.0	29	1.5	25	1.2
		90	303	129	33.7	2.0	29	1.5	25	1.2
40	1 1/2"	130	384	161	48.3	2.0	41	1.5	38	1.2
50	2	130	407	192	60.3	2.0	53	1.5	51	1.2

ASME BPE and BS 4825

Orifice	•	Actua- tor size Ø			ASME I	BPE	BS 482	5
[mm]	[inch]	[mm]	HG	LS	Ø DS	ws	Ø DS	ws
15	1/2"	70	257	108	12.70	1.65	12.70	1.2
20	3/4"	70	267	117	19.05	1.65	19.05	1.2
25	1"	70	270	127	25.40	1.65	25.40	1.65
		90	303	127	25.40	1.65	25.40	1.65
40	1 1/2"	130	384	159	38.10	1.65	38.10	1.65
50	2	130	407	190	50.80	1.65	50.80	1.65

Clamp connection



DIN 32676 and ASME BPE

Orific	е	Actuator size Ø		DIN 3	32676			ASME B	PE			
[mm]	[inch]	[mm]	НG	LC	Ø D1C	Ø D2C	Ø D3C	LC long dimen- sion	short dimen- sion	Ø D1C	Ø D2C	Ø D3C
15	1/2"	70	257	110	34	27.5	16	108	89	25	-	9.4
20	3/4"	70	267	119	34	27.5	20	117	102	25	-	15.75
25	1"	70	270	129	50.5	43.5	26	127	114	50.5	43.5	22.2
		90	303	129	50.5	43.5	26	127	114	50.5	43.5	22.2
40	1 1/2"	130	384	161	50.5	43.5	38	159	140	50.5	43.5	34.9
50	2	130	407	192	64.0	56.5	50	190	159	64.0	56.5	47.6

On request: ISO 2852


Orifice	•	Actuator size Ø					
[mm]	[inch]	[mm]	HG	LC	Ø D1 C	Ø D2 C	Ø D3 C
25	1″	70	270	129	50.5	43.5	22.6
		90	303	129	50.5	43.5	22.6



Dimensions for valve system On/Off ELEMENT Type 8801-DF [mm], continued

Dimensions valve system On/Off ELEMENT Type 8801-DF-M with control head Type 8695 [mm]

Welded connection




EN ISO 1127/ISO 4200 and DIN 11850 S2

Orifice		Actuator size			EN ISO 112	7/ ISO 4200	DIN 1185	0 Serie 2
[mm]	[inch]	[mm]	Н	LS	Ø DS	ø ws	Ø DS	ø ws
8	1/4"	50	223	90	13.5	1.6	-	-
10	3/8"	50	238	110	17.2	1.6	13.0	1.5

On request: ASME BPE and BS 4825

Orifice		Actuator size Ø			ASME	BPE	BS 48	25
[mm]	[inch]	[mm]	Н	LS	Ø DS	ws	Ø DS	WS
8	1/4″	50	223	78	6.35	0.89	6.35	1.2
10	3/8"	50	238	108	9.53	0.89	9.53	1.2

Clamp connection



DIN 32676

Orifice		Actuator size		DIN :	32676		
[mm]	[inch]	[mm]	н	LC	øD1 C	øD2 C	øD3 C
10	3/8"	50	238	110	34	27.5	16

ASME BPE

Orifice		Actuator size		ASME BPE				
[mm]	[inch]	[mm]	н	LC long dimension	short dimension	ØD1 C	ØD2 C	ØD3 C
8	1/4"	50	223	78	64.5	25	21.8	3.95
10	3/8"	50	238	89	89	25	21.8	9.4



lease fill out and send to your neare	st Bürkert facilitv* wit	h vour inquiry or ord	der	th
Company	or Burkert ruently with	Contact person		in be
Customer no.		Department		0
Address		Tel./Fax		
Postcode/town		E-mail		
= mandatory fields to fill out	Quantit	<i>y</i>	Required of	delivery date
Operating data				
Pipe line	DN	PN PN		
Pipe material				
Process medium				
Type of media	Liquid	Stea	am Ga	ıs
Valve features				
valve realares				
Specification key				
from last page	internal	um external	um	
Surface finish (if not standard)	internal	μm external min	μm	max
from last page Surface finish (if not standard)	internal	μm external min.	μm	max.
Surface finish (if not standard) Pilot pressure Control unit features				
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz	es ø70/ø90/ø130 mm	min.	For actuator size	ø50 mm
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690	es ø70/ø90/ø130 mm	min.	For actuator size	ø50 mm
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function	es ø70/ø90/ø130 mm Control Head Type Pneumatic function	min. me 8691 More info.	For actuator size Control Head Type 8	e e50 mm 695 More info.
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Double-acting	es ø70/ø90/ø130 mm	min.	For actuator size	e ø50 mm
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Without pilot valve	es ø70/ø90/ø130 mm Control Head Type Pneumatic function	min. me 8691 More info.	For actuator size Control Head Type 8	e e50 mm 695 More info.
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Without pilot valve Position feedback	es ø70/ø90/ø130 mm Control Head Type Pneumatic function Single-acting Pilot air ports	min. me 8691 More info.	For actuator size Control Head Type 8 Pneumatic function Single-acting	695 More info. Double-acting
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Without pilot valve Position feedback 1x inductive Qx inductive	es ø70/ø90/ø130 mm Control Head Type Pneumatic function Single-acting Pilot air ports Push-in connector Thread G 1/8"	min. Dee 8691 More info. Double-acting	For actuator size Control Head Type 8 Pneumatic function Single-acting Pilot air ports	695 More info. Double-acting
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Without pilot valve Position feedback 1x inductive 2x inductive (NAMUR) 2x inductive (NAMUR)	es ø70/ø90/ø130 mm Control Head Type Pneumatic function Single-acting Pilot air ports Push-in connector Thread G 1/8"	min. Dee 8691 More info. Double-acting	For actuator size Control Head Type 8 Pneumatic function Single-acting Pilot air ports Push-in connector exte	695 More info. Double-acting
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Without pilot valve Position feedback 1x inductive 1x inductive (NAMUR) 2x inductive (NAMUR) 1x mechanical 2x mechanical	es ø70/ø90/ø130 mm Control Head Type Pneumatic function Single-acting Pilot air ports Push-in connector Thread G 1/8"	min. Dee 8691 More info. Double-acting	For actuator size Control Head Type 8 Pneumatic function Single-acting Pilot air ports Push-in connector exte Thread G 1/8"	695 More info. Double-acting
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Without pilot valve Position feedback 1x inductive 1x inductive (NAMUR) 2x inductive (NAMUF) 1x mechanical Supply voltage	es ø70/ø90/ø130 mm Control Head Type Pneumatic function Single-acting Pilot air ports Push-in connector Thread G 1/8" Communication	min. Dee 8691 More info. Double-acting	For actuator size Control Head Type 8 Pneumatic function Single-acting Pilot air ports Push-in connector exte Thread G 1/8" Communication	695 More info. Double-acting
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Without pilot valve Position feedback 1x inductive 1x inductive (NAMUR) 2x inductive (NAMUR) 1x mechanical Supply voltage 24 V / DC (ATEX Zone 2/22)	es ø70/ø90/ø130 mm Control Head Type Pneumatic function Single-acting Pilot air ports Push-in connector Thread G 1/8" Communication ASI	min. Doe 8691 Double-acting external ø 6mm or 1/4"	For actuator size Control Head Type 8 Pneumatic function Single-acting Pilot air ports Push-in connector exte Thread G 1/8" Communication	695 More info. Double-acting
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Without pilot valve Position feedback 1x inductive (NAMUR) 2x inductive (NAMUF) 1x mechanical 2x mechanical Supply voltage 24 V / DC (ATEX Zone 2/22) Ex ia IIC T6 (ATEX Zone 1)	es ø70/ø90/ø130 mm Control Head Type Pneumatic function Single-acting Pilot air ports Push-in connector Thread G 1/8" Communication ASI Multipol M12	min. Doe 8691 Double-acting external ø 6mm or 1/4"	For actuator size Control Head Type 8 Pneumatic function Single-acting Pilot air ports Push-in connector exte Thread G 1/8" Communication	695 More info. Double-acting
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Without pilot valve Position feedback 1x inductive (NAMUR) 2x inductive (NAMUF) 1x mechanical 2x mechanical Supply voltage 24 V / DC (ATEX Zone 2/22) Ex ia IIC T6 (ATEX Zone 1) Pilot air ports Push-in connector Thread G 1/8"	es ø70/ø90/ø130 mm Control Head Type Pneumatic function Single-acting Pilot air ports Push-in connector Thread G 1/8" Communication ASI Multipol M12 Flat cable clip,	min. Doe 8691 Double-acting external ø 6mm or 1/4"	For actuator size Control Head Type 8 Pneumatic function Single-acting Pilot air ports Push-in connector exte Thread G 1/8" Communication	695 More info. Double-acting
Surface finish (if not standard) Pilot pressure Control unit features For actuator siz Pneumatic Control Unit Type 8690 Pneumatic function Single-acting Without pilot valve Position feedback 1x inductive (NAMUR) 2x inductive (NAMUR) 1x mechanical 2x mechanical Supply voltage 24 V / DC (ATEX Zone 2/22) Ex ia IIC T6 (ATEX Zone 1) Pilot air ports	es ø70/ø90/ø130 mm Control Head Type Pneumatic function Single-acting Pilot air ports Push-in connector Thread G 1/8" Communication ASI Multipol M12 Flat cable clip,	min. Doe 8691 Double-acting external ø 6mm or 1/4"	For actuator size Control Head Type 8 Pneumatic function Single-acting Pilot air ports Push-in connector exte Thread G 1/8" Communication	695 More info. Double-acting

www.burkert.com

^{*} To find your nearest Bürkert facility, click on the orange box $\,\to\,$




Valve system On/Off Classic Type 8801-DF – request for quotation, cont.

Control unit features					
Pilot valve	Stroke limitation				
Pilot valve	Stroke limitation				
Power supply	Min./max. stroke limitation, with visual position indicator Max. stroke limitation, without visual position indicator				
Please specify item no. if known:	Please specify item no. if known:				
Certifications					
Attestation of compliance with the order EN-ISO 10204 2.1 (Item-No. 440 788) Test report EN-ISO 10204 2.2 (Item-No. 803 722) Certification of Conformity for Raw Material EN-ISO 10204 3.1 (included in delivery) EN161 (European Gas Device guideline) FDA - USP certificate					
Comment / sketch					

burkert

Valve features, specification key



Welded connection

Port con	n EN ISO 1127/	N ISO 1127/		DIN 11850					JIS	JIS
[mm]	ISO 4200	SMS 3008	Series 0	Series 1	Series 2	Series 3	BS 4825	ASME BPE	Sanitary	Utility
8	SA40=13.5x1.6		SC42=10x1.0				SODB=6.35x1.2	SA90=6.35x0.89	SA70=13.8x1.65	
10	SA41=17.2x1.6			SF40=12x1.0	SD40=13x1.5	SE40=14x2.0	SODC=9.53x1.2	SA91=9.53x0.89	SA71=17.3x1.65	
15	SA42=21.3x1.6		SC43=18x1.5	SF41=18x1.0	SD42=19x1.5	SE42=20x2.0	SODD=12.7x1.2	SA92=12.7x1.65	SA72=21.7x2.1	
20	SA43=26.9x1.6		SC44=22x1.5	SF42=22x1.0	SD43=23x1.5	SE43=24x2.0	SODE=19.05x1.2	SA93=19.05x1.65	SA76=27.2x2.1	SA80=27.2x2.1
25	SA44=33.7x2.0	SA60=25.0x1.2	SC45=28x1.5	SF43=28x1.0	SD44=29x1.5	SE44=30x2.0	SODF=25.4x1.65	SODF=25.4x1.65	SA73=25.4x1.2	SA81=34x2.0
32	SA45=42.4x2.0		SC46=34x1.5	SF44=34x1.0	SD45=35x1.5	SE45=36x2.0				SA83=42.7x2.0
40	SA46=48.3x2.0	SA62=38.0x1.2	SC47=40x1.5	SF45=40x1.0	SD46=41x1.5	SE46=42x2.0	SODH=38.1x1.65	SODH=38.1x1.65	SA74=38.1x1.2	SA84=60.5x2.0
50	SA47=60.3x2.0	SA63=51.0x1.2	SC48=52x1.5	SF46=52x1.0	SD47=53x1.5	SE47=54x2.0	SODI=50.8x1.65	SODI=50.8x1.65	SA75=50.8x1.5	

Clamp connection

Port conn	ISO 2852	ASME BPE	DIN 32676	
[mm]	SMS 3017	short dimension	long dimension	
8	TC51=Clamp 34 - für Rohr ISO 4200	TI40=Clamp 25 - Rohr 6.35x0.89	TG40=Clamp 25 - Rohr 6.35x0.89	
10	TC41=Clamp 34 - für Rohr ISO 4200	TI41=Clamp 25 - Rohr 9.53x0.89	TG41=Clamp 25 - Rohr 9.53x0.89	TD41=Clamp 34 - Rohr 13x1.5
15	TC42=Clamp 34 - für Rohr ISO 4200	TI42=Clamp 25 - Rohr 12.7x1.65	TG42=Clamp 25 - Rohr 12.7x1.65	TD42=Clamp 34 - Rohr 19x1.5
20	TC43=Clamp 50.5 - für Rohr ISO 4200	TI43=Clamp 25 - Rohr 19.05x1.65	TG43=Clamp 25 - Rohr 19.05x1.65	TD43=Clamp 34 - Rohr 23x1.5
25	TC44=Clamp 50.5 - für Rohr ISO 4200	TI44=Clamp 50.5 - Rohr 25.4x1.65	TG44=Clamp 50.5 - Rohr 25.4x1.65	TD44=Clamp 50.5 - Rohr 29x1.5
40	TC46=Clamp 64 - für Rohr ISO 4200	TI46=Clamp 50.5 - Rohr 38.1x1.65	TG45=Clamp 50.5 - Rohr 38.1x1.65	TD46=Clamp 50.5 - Rohr 41x1.5
50	TC47=Clamp 77.5 - für Rohr ISO 4200	TI47=Clamp 64 - Rohr 50.8x1.65	TG46=Clamp 64 - Rohr 50.8x1.65	TD47=Clamp 64 - Rohr 53x1.5