



Level



Pressure



Flow



Temperature

Liquid  
Analysis

Registration

Systems  
Components

Services



Solutions

## Technical information

# Easytemp™

## TSM470G / TSM470F / TSM470P

### Compact RTD Transmitter

4-wire Pt100, class A, PC programmable. The economical and technical alternative to unreliable direct wiring to the control room



### Application

The hermetically sealed easytemp™ compact RTD transmitter provide a 4 to 20 mA solution for temperature measurement and is intended for simple measuring tasks from -60 to 320 °F.

The ideal operation location for TSM470G with ½" NPT process fitting is in tanks and pipes that are not exposed to any high pressure or extreme temperature.

Sanitary design of TSM470F and TSM470P with Tri-Clamp connection meets 3-A sanitary standards. TSM470P sensors are electro-polished ( $R_a = 20 \mu\text{in}$ , or 240 grit) to meet requirements of the pharmaceutical industry. The TSM470F is polished to a  $R_a = 32 \mu\text{in}$  (150 grit) finish.

### Features and benefits

- Sensor and electronics potted to protect against condensation
- 4 to 20 mA loop-powered, compact design
- M12 plug-in micro connector for easy start up
- High accuracy all-in-one-system
- Configuration, visualization and maintenance with PC, using ReadWin® 2000 operating freeware

- Preset measuring range
- Breakdown information in event of sensor break or sensor short-circuit, enables a quick maintenance intervention
- UL recognized component to UL 3111-1
- CSA General purpose
- Electromagnetic compatibility to IEC61326 for use in noisy environments
- Customer specific measurement range setting for high flexibility
- Long term stability: < 0.05% per year
- Reliable measurement during variable ambient temperature
- Compact RTD transmitter completely made of stainless steel, components in contact with the process SST 316L
- Sanitary and threaded process connections and various insertion length for high flexibility
- Pt100, accuracy class A (IEC60751) in 4-wire connection

## Function and system design

<b>Measuring principle</b>	Electronic acquisition and conversion of input signals in industrial temperature measurement.
<b>Measuring system</b>	The compact thermometer consists of a complete sensor with Pt100 (class A, 4-wire connection), process connection and built-in electronics with an M12x1 micro connector and convert the Pt100 input signal into a temperature proportional 4 to 20 mA signal.

## Input

Measuring principle	Temperature		
Measuring range	Designation	Measuring range limits	Min. span
	Pt100 as per IEC 60751	-51 to 160 °C (-60 to 320 °F)	10 °C (18 °F)
	<div>■ Connection type: 4-wire connection</div> <div>■ Sensor current: ≤ 0.6 mA</div>		

## Output values


<b>Output signal</b>	analog 4 to 20 mA, 20 to 4 mA		
<b>Breakdown information</b>	<b>Breakdown information to NAMUR NE43</b> Breakdown information is created when the measuring information is invalid or not present anymore and gives a complete listing of all errors occurring in the measuring system.		
			Signal (mA)
Under ranging	Standard		3.8
Over ranging	Standard		20.5
Sensor break; sensor short circuit low	To NAMUR NE43		$\leq 3.6$
Sensor break; sensor short circuit high	To NAMUR NE43		$\geq 21$

<b>Source impedance</b>	max. $(V_{\text{power supply}} - 10\text{V}) / 0.022\text{ A}$ (current output) e. g. $(24\text{ V} - 10\text{ V}) / 0.022\text{ A} = 636.4\ \Omega$
<b>Transmission behavior</b>	temperature linear
<b>Min. current consumption</b>	$\leq 3.5\text{ mA}$
<b>Current limit</b>	$\leq 23\text{ mA}$
<b>Switch-on delay</b>	2 s (during power up $I_a \leq 3.8\text{ mA}$ )

Wiring

Electrical connection cables must comply with 3-A® standard, must be smooth, corrosion resistant and cleanable.

Electrical connection



Electrical connection of the compact thermometer (viewed from above)  
– M12 plug, 4-pin

- Pin 1: Power supply 10 to 35 V DC; Current output 4 to 20 mA
- Pin 2: PC configuration cable connection
- Pin 3: Power supply 0 V DC; Current output 4 to 20 mA
- Pin 4: PC configuration cable connection

The connection cable 5 m is for the 4...20 mA signal and will be connected with pin 1 and 3 as shown in the picture. The pins 2 and 4 are for the communication with the computer. If you look on the communication adapter then you see that there are two male pins that are making connection to the two shortend metal pins 2 and 4. By the way the supply for the TSM470 for the communication is done by the computer interface.

Supply voltage                      U<sub>b</sub>= 10 to 35 V DC, polarity protected

Residual ripple                    Allowable ripple U<sub>ss</sub> ≤ 3 V at U<sub>b</sub> ≥ 13 V, f<sub>max.</sub> = 1 kHz

Performance characteristics

Electronics response time        1 s

Response time TSM470  
63% response time per ASTM E644

	TSM470G	TSM470F	TSM470P
Tube diameter 1/4" OD, 316L	8 s	4 s	-
Tube diameter 3/8" OD reduced 3/16" OD, 316L	-	3 s	-
Tube diameter 5/32" OD, 316L	-	-	2 s

Reference operating conditions      Calibration temperature: +25 °C ± 5 °C (77 °F ± 9 °F)

**Maximum measured error****Electronics**

0.1 °C (0.18 °F) or 0.08%.  
 % refer to the set span. The highest value is valid.


**Sensor**

- Class A tolerance as per IEC60751, at operating temperature range of -51 to 160 °C (-60 to 320 °F).
- Accuracy =  $\pm 0.15 + 0.002 \cdot |t|$  [°C]


$|t|$  = numerical value of the temperature in °C, unsigned.

**Compact RTD transmitter**

Initial accuracy:



*Transmitter range 360 °F*



*Transmitter range 200 °C*

**Influence of power supply**

$\leq \pm 0.01\%/V$  deviation from 24 V  
 Percentages refer to the full scale value.

**Long-term stability**

$\leq 0.1$  °C/year ( $\leq 0.18$  °F/year) or  $\leq 0.05\%/year$   
 Values under reference operating conditions. % refer to the set span. The highest value is valid.

**Influence of ambient temperature (temperature drift)**

Pt100 resistance thermometer:  
 $T_d = \pm (8.3 \text{ ppm}/^\circ\text{F} * (\text{range end value} + 328) + 27.8 \text{ ppm}/^\circ\text{F} * \text{preset meas. range}) * \Delta\vartheta$   
 $\Delta\vartheta$  = deviation of the ambient temperature according to reference condition (73.4 °F ± 9 °F).

**Influence of load**


± 0.02%/100 Ω  
 Percentages refer to the full scale value.

# **Installation conditions**

**Orientation**

No restrictions, but self draining. If applicable leak detection hole must be at the lowest point.

**Installation instructions**



Mounting location

Pipe installation example of TSM470G	Pipe installation example in hygienic applications of TSM470F and TSM470P
<p>A At angle sections, against the direction of flow                      B In smaller pipes, turned against the direction of flow                      C Perpendicular to the direction of flow. For TSM470F and TSM470P installation with minimal 3° inclination because of self draining.                      In pipes with a small cross section the sensor tip should reach or extend slightly past the center line of the pipe (= L).</p>	

Care should be taken by the user in the execution of the welding on the process side (suitable weld material, welding radius > 3.2 mm, absence of pits, folds, crevices, ...). As a general rule, the thermometers should be installed in such a way that does not adversely affect their cleanability (3-A® requirements must be adhered to).

# **Environmental conditions**

**Ambient temperature limits**

-40 to +85 °C (-40 to 185 °F)

**Storage temperature**

-40 to +100 °C (-40 to 212 °F)

**Climate class**

As per IEC60 654-1, class C

**Degree of protection**

NEMA Type 6P RATED (IP67)

**Shock and vibration resistance** 4g / 2 to 150 Hz as per IEC 60 068-2-6

**Electromagnetic compatibility (EMC)**

**CE Electromagnetic Compatibility Compliance**

The device meets all requirements listed under IEC61326 Amendment 1, 1998 and NAMUR NE 21.

This recommendation is an uniform and practical way of determining whether the devices used in laboratory and process control are immune to interference with an objective to increase its functional safety.

Discharge of static electricity	IEC61000-4-2	6 kV contact	
Electromagnetic fields	IEC61000-4-3	80 to 2000 Hz	10 V/m
Burst (signal)	IEC61000-4-4	1 kV	
Transient voltage	IEC61000-4-5	1 kV unsym. / 0.5 kV sym.	
HF coupling	IEC61000-4-6	0.15 to 80 MHz	10 V
Line interference	IEC61000-4-16	10 kHz to 150 kHz	10 V

**Condensation** allowed

**Immersion** Minimum immersion per ASTM E644,  $\Delta T \leq 0.05 \text{ }^{\circ}\text{C}$  (0.09  $^{\circ}\text{F}$ )

Version	Minimum Immersion (Inch)
TSM470G	1½ "
TSM470F	¾ "
TSM470P	¾ "

## Process

**Process temperature limits** -51 to 160  $^{\circ}\text{C}$  (-60 to 320  $^{\circ}\text{F}$ ).


Caution!

Restrictions dependent on the process connection and ambient temperature are possible:

max. ambient temperature	max. process temperature
to 23.9 $^{\circ}\text{C}$ (75 $^{\circ}\text{F}$ )	no restrictions
to 37.8 $^{\circ}\text{C}$ (100 $^{\circ}\text{F}$ )	140.6 $^{\circ}\text{C}$ (285 $^{\circ}\text{F}$ )
to 60 $^{\circ}\text{C}$ (140 $^{\circ}\text{F}$ )	121.1 $^{\circ}\text{C}$ (250 $^{\circ}\text{F}$ )
to 85 $^{\circ}\text{C}$ (185 $^{\circ}\text{F}$ )	101.7 $^{\circ}\text{C}$ (215 $^{\circ}\text{F}$ )

**Process pressure limits**

p/T load curve according to Dittrich for TSM470G. Maximum static pressure: 4000 PSI (at 25 °C/77 °F).




$L$  = insertion length  
 $v_a$  = flow velocity air  
 $v_{W/S}$  = flow velocity water or steam

*(Avoid resonance frequency as this will cause damage to the probe! Resonance frequency occurs when permanent flow velocity is at 31 ft/s (air) for the 5 1/4 " and / or 13 ft/s (air) for 8 1/4 " probe.)*


## Mechanical construction

### Design, dimensions


#### TSM470G



#### TSM470F



#### TSM470P



#### Surface Finish TSM470F & TSM470P

32 micro-inches  $R_a$  and 20 micro-inches  $R_a$  are the two standard finishes provided for Milk service and Bioprocessing Equipment services respectively. The 32 micro-inch  $R_a$  maximum is defined in "3-A Sanitary Standards for Sensors and Sensor Fittings and Connections used on Milk and Milk Products Equipment, Number 74-03". The 20 micro-inch maximum is defined in "ASME BPE-2002, Bioprocessing Equipment".



### Polishing Procedures

The wetted surfaces of the sensors and sanitary fittings are mechanically polished to achieve a 32 micro-inch maximum surface finish, in accordance with 3-A Standard Number 74-03. Minimal material has been removed to achieve the indicated surface finish. Residual polishing compounds are removed after polishing operations are completed on all surfaces and sanitary end fittings. The end fitting material and sensor sheath are both composed of 316L stainless steel.

The wetted surfaces of the sensors and sanitary fittings are electropolished to achieve a 20 micro-inch maximum surface finish, in accordance with ASME BPE-2002. All electropolished surfaces have not undergone any passivation. Minimal material has been removed to achieve the indicated surface finish. The end fitting material and sensor sheath are both composed of 316L stainless steel.

### Packaging

Sanitary sensors and fittings are individually bagged and sealed to ensure cleanliness upon delivery to the final customer.


### Weight


L in Inches (mm)	3¼" (82.55)	5¼" (133.35)	8¼" (209.45)
TSM470G	95 g	103 g	115 g
L in Inches (mm)	2" (50.8)	4" (101.6)	6" (152.4)
TSM470F-_B1	141 g	151 g	161 g
TSM470F-_B2	161 g	188 g	215 g
TSM470F-_C1	198 g	208 g	218 g
TSM470F-_C2	218 g	245 g	272 g
L in Inches (mm)	¾" (19.05)	1¼" (31.75)	2¾" (69.85)
TSM470P	67 g	69 g	72 g

### Material

Transmitter housing: stainless steel (SST).  
Wetted parts: SS 316L (1.4404).

### Process connection



**TSM470F and TSM470P, Tri-clamp® connection (3-A® marked)**

(*)							(**)
DN	A	B	C	d	D std.	D strong	PNmax (bar)
½”(****)	20,0	25,0	3,6	9,5	-	12,7	-
¾”(****)				15,8	-	19,0	-
1”	43,5	50,5	2,85	22,2	-	29,5	-
1½”				34,9	25,4	-	9÷20,7
					-	42,6	-
2”	56,5	64,0		47,6	38,1	-	9÷20,7
					-	55,7	-
				50,8	-	9÷17,2	

(\*) Pipes according to ISO 2037 and BS 4825 Part1.

(\*\*) Depends on clamping ring type, at 121°C with suitable gasket.

(\*\*\*) MicroClamp.

**Terminals**

M12 plug-in micro connector (see Chap. Wiring).

## Human interface

**Display elements**

No display elements are present directly on the transmitter.  
The measured value display, for example, can be called up using the ReadWin® 2000 PC software.

**Operating elements**

No operating elements are present directly on the transmitter. The temperature transmitter is configured via remote operation with the ReadWin® 2000 PC software.

**Remote operation****Configuration**

TSM470A configuration kit, can be configured using a PC operating program (ReadWin® 2000).

**Interface**

PC-interface connecting cable TTL -/- RS232 or USB-port with plug-in connection.

**Configurable parameters**

Measuring dimension (°C/°F), measuring ranges, failure mode, output signal (4 to 20 / 20 to 4 mA), offset, filter, set tag number (8 characters), output simulation.

---

## Certificates and approvals

---

<b>3A</b>	A Sanitary Standards for Sensors, Connections and Sensor Fittings used on Milk and Milk Products Equipment, Number 74-03
<b>CE-Mark</b>	This unit complies with the legal requirements laid out within the EU regulations.
<b>Other standards and guidelines</b>	<ul style="list-style-type: none"> <li>■ IEC60529: Degrees of protection by housing (IP-Code).</li> <li>■ IEC61010: Safety requirements for electrical measurement, control and laboratory instrumentation.</li> <li>■ IEC1326: Electromagnetic compatibility (EMC requirements).</li> <li>■ IEC60751: Industrial platinum resistance thermometer</li> <li>■ ASTM E644: American society for testing and materials, standard test methods for testing industrial resistance thermometers.</li> <li>■ NAMUR Standardization association for measurement and control in chemical and pharmaceutical industries. (<a href="http://www.namur.de">www.namur.de</a>).</li> <li>■ NEMA - ANSI / NEMA 250 Standardization association for the electrical industry.</li> </ul>
<b>UL</b>	Recognized component to UL 3111-1
<b>CSA GP</b>	CSA General Purpose

## Ordering information






### Product structure

TSM470F-	Easytemp® Compact RTD transmitter TSM470F Compact sanitary Pt100, class A sensor with transmitter, loop powered 4 to 20 mA, M12 quick connector, Sanitary version meets 3-A standard, surface finish R <sub>a</sub> min. 32 micro inch (150 grit), UL recognized component, CSA General Purpose				
Approval					
A	Non hazardous area				
Process connection/Material					
B	1" + 1 ½" Tri-clamp connection, 316L, 3A				
C	2" Tri-clamp connection,316L, 3A				
Y	Special version, TSP-no. to be specified				
Tube OD diameter; material					
1	¼", 316L				
2	3/8" reduced 3/16", 316L				
9	Special version, TSP-no. to be specified				
Immersion length L					
A	2 inch				
B	4 inch				
C	6 inch				
X	.... inch (increment 0.25)				
Y	Special version, TSP-no. to be specified				
Configuration					
AA	Range 0 to 100 °F				
AB	Range 0 to 200 °F				
AC	Range 0 to 300 °F				
AD	Range -40 to 140 °F				
AE	Range -40 to 200 °F				
BB	Range -40 to 60 °C				
BC	Range -30 to 60 °C				
BD	Range -30 to 150 °C				
BE	Range -30 to 70 °C				
BG	Range -20 to 20 °C				
BH	Range -20 to 60 °C				
BI	Range -10 to 40 °C				
BK	Range 0 to 50 °C				
BL	Range 0 to 100 °C				
BM	Range 0 to 150 °C				
XX	Customised range (min. span 10 K)				
YY	Special version, TSP-no. to be specified				
Version					
1	Standard				
2	with certificate of compliance				
3	Cable M12x1, L = 5 m (16.4 ft)				
9	Special version, TSP-no. to be specified				
Additional option					
K	None				
L	Material Traceability Certificate				
M	Loop Calibration Certificate				
Y	Special version, TSP-no. to be specified				
TSM470F-	A				⇐ Order code (complete)

TSM470P-		Easytemp® Compact RTD transmitter TSM470P Compact sanitary Pt100, class A sensor with transmitter, loop powered 4 to 20 mA, M12 quick connector, Sanitary version meets 3-A standard, surface finish R <sub>a</sub> min. 20 micro inch (240 grit), electro polish, UL recognized component, CSA GP									
		Approval									
		A		Version for General purpose area							
		Process connection									
		A		½" + ¾" Tri-clamp, 316L, 3A							
		Y		Special version, TSP-no. to be specified							
		Tube OD diameter, material									
		1		Diameter 5/32" OD, 316L							
		9		Special version, TSP-no. to be specified							
		Insertion length L									
		A		1 ¼ inch							
		B		2 ¾ inch							
		C		¾ inch							
		Y		Special version, TSP-no. to be specified							
		Configuration range									
		AA		range 0 to 100 °F							
		AB		range 0 to 200 °F							
		AC		range 0 to 300 °F							
		AD		range -40 to 140 °F							
		AE		range -40 to 200 °F							
		BB		range -40 to 60 °C							
		BC		range -30 to 60 °C							
		BD		range -30 to 150 °C							
		BE		range -30 to 70 °C							
		BG		range -20 to 20 °C							
		BH		range -20 to 60 °C							
		BI		range -10 to 40 °C							
		BK		range 0 to 50 °C							
		BL		range 0 to 100 °C							
		BM		range 0 to 150 °C							
		XX		Customised range (min. span 10 K)							
		YY		Special version, TSP-no. to be specified							
		Version									
		1		Standard version							
		2		with certificate of compliance							
		3		Cable M12x1, L = 5 m (16.4 ft)							
		9		Special version, TSP-no. to be specified							
		Additional option									
		K		None							
		L		Material Traceability Certificate							
		Y		Special version, TSP-no. to be specified							
TSM470P-		A								⇐ Order code (complete)	

TSM470G-	Easytemp® Compact RTD transmitter TSM470G Compact Pt100, class A sensor with transmitter, loop powered 4 to 20 mA, M12 quick connector, UL recognized component, CSA General Purpose				
Approval					
A	Non-hazardous area				
Process connection/Material					
A	½" - 14 NPT, 316L				
C	one time compression fitting, 1/8" NPT, 316L				
D	re-adjustable compression fitting, 1/8" NPT, 316L				
E	one time compression fitting, ¼" NPT, 316L				
F	re-adjustable compression fitting, ¼" NPT, 316L				
P	Thread G½" BSP, 316L				
Q	not selected				
Y	Special version, TSP-no. to be specified				
Tube OD diameter/Material per 1 inch					
1	Diameter ¼" OD, 316L				
9	Special version, TSP-no. to be specified				
Immersion length L					
A	3 1/4 inch				
B	5 1/4 inches				
C	8 1/4 inches				
X	..... Inch (increment 0.25)				
Y	Special version, TSP-no. to be specified				
Configuration range					
AA	range 0 to 100 °F				
AB	range 0 to 200 °F				
AC	range 0 to 300 °F				
AD	range -40 to 140 °F				
AE	range -40 to 200 °F				
BB	range -40 to 60 °C				
BC	range -30 to 60 °C				
BD	range -30 to 150 °C				
BE	range -30 to 70 °C				
BG	range -20 to 20 °C				
BH	range -20 to 60 °C				
BI	range -10 to 40 °C				
BK	range 0 to 50 °C				
BL	range 0 to 100 °C				
BM	range 0 to 150 °C				
XX	Customised range (min. span 10 K)				
YY	Special version, TSP-no. to be specified				
Version					
1	Standard version				
3	Cable M12x1, L = 5 m (16.4 ft)				
9	Special version, TSP-no. to be specified				
Additional option					
K	None				
M	Loop calibration certificate				
L	Special version, TSP-no. to be specified				
TSM470G-	A				← Order code (complete)

## Accessories

Order number	Accessory
<b>TSM470A-VM</b> 	Configuration kit: Setup program (ReadWin® 2000) and PC serial interface connection cable (TTL/RS 232C) for configuration of the TSM470G / TSM470F / TSM470P.
<b>TXU10-BA</b> 	Configuration kit: Setup program (ReadWin® 2000) and PC serial interface connection cable for PC with USB port. Adapter M12 + 4 pin plug
<b>TSM470A-VN</b> 	Connector unshielded, female, angled, M12 A coded, 4-pos.
<b>SONDTT-AG</b> 	CD-ROM with all operation and instruction manuals, Endress+Hauser data acquisition, system components, temperature measurement.
<b>51005148</b> 	5 m (16.4 ft) PVC connecting cable with M12x1 microconnector
<b>51007657</b>	Adapter Upgrade TXU10 (M12 + 4 pin plug)

## Documentation

- Fields of activities (FA) 'Temperature measurement' (FA006T/09/en)
- Compact instructions 'Easytemp™ TSM470' (KA148R/24/ae)
- Operating manual 'Easytemp™ TSM470 compact RTD transmitter' (BA164R/24/ae)

USA	Canada	México	Instruments International
Endress+Hauser, Inc. 2350 Endress Place Greenwood, IN 46143 USA  Tel.317-535-7138 Fax317-535-8498 Sales888-ENDRESS Service800-642-8737 inquiry@us.endress.com www.us.endress.com	Endress+Hauser Canada 1075 Sutton Drive Burlington, ON L7L 5Z8 Canada  Tel.905-681-9292 800-668-3199 Fax905-681-9444 www.ca.endress.com	Endress+Hauser, México, S.A. de C.V.F Fernando Montes de Oca 21 Edificio A Piso 3 Fracc. Industrial San Nicolas 54030. Tlalnepantla de Baz Estado de México México  Tel.+52 55 5321 2080 Fax+52 55 5321 2099 eh.mexico@mx.endress.com www.mx.endress.com	Endress+Hauser Instruments International AG Kaegenstrasse 2 4153 Reinach Switzerland  Tel.+41 61 715 81 00 Fax+41 61 715 25 00 www.endress.com info@ii.endress.com

**Endress+Hauser**   
People for Process Automation